

BauderTOP VENT NSK

Verlegeanleitung

Laying instruction

Verlegung

BauderTOP VENT NSK kann sowohl parallel zur Traufe als auch Traufe/ First verlegt werden. Die Befestigung erfolgt verdeckt im oberen/ seitlichen selbstklebend ausgerüsteten Überlappungs-bereich. Kopfstöße werden mit einem Streifen selbstklebender Anschlussbahn BauderTEC PMK unterlegt. Ebenso werden Anschlüsse und Details mit Streifen der selbstklebenden Anschlussbahn BauderTEC PMK hergestellt. Sollte die Klebekraft der selbstklebenden Überlappungen als auch der Anschlussbahn bei kalten Außentemperaturen zu gering sein, kann diese mit einem Heißluftfön aktiviert werden. Sämtliche Naht und Stoßverklebungen sind mit einer Andrückrolle abzurollen.

Laying

BauderTOP VENT NSK can be laid either parallel to the eaves or in eaves-to-ridge direction. Carry out concealed fastening in the top/side overlap area, which is self-adhesive. Underlay end joints with BauderTEC PMK self-adhesive connecting strip. Connections and details also require BauderTEC PMK self-adhesive connecting strip. If the adhesive strength of the self-adhesive overlaps and connecting strips is inadequate in low outside temperatures, it can be increased by using a hot-air blower. Press down all seams and butt joints with a roller.